

## CD-01U/CD-01PRO – Firmware Update Procedure

### Creating the Firmware Update CD

1. Must have a blank CD-R and disc burning software. You will be creating a “data” disc.
2. Download the latest version of the firmware from the TASCAM website. Burn this firmware file onto a blank CD-R disc. (Use the “Disc At Once” method that complies with ISO9660 Level 1: MS-DOS compatible mode)

### NOTES:

Be sure that the power to the unit is not interrupted during the update process otherwise the unit’s ROM data can be damaged. This can result in having to replace certain physical components inside the unit.

### Update Procedure

1. With no disc loaded, simultaneously press and hold the SEARCH (<<) and SEARCH (>>) buttons. While holding these buttons, press the EJECT button so that “UPDATE IN” is displayed. This indicates that the update mode has been enabled.
2. Insert the Firmware Update CD you created.
3. The display will read “OLD Ver”. With each press of the PITCH dial, the display will show “NEW Ver”, “SURE” and then “UPDATE”. At this point the update process will begin. When the process is completed, the display will show “COMPLETE”. Press the EJECT button to remove the Firmware Update CD. Power the unit off and then on again.

### Initializing the Preset Menu

1. Press and hold the SHIFT button while pressing the PITCH dial to enable the Menu Mode.
2. Rotate the PITCH dial until menu 14 (F-Pre) is displayed. Press the PITCH dial. The display will show “SURE”.
3. Press the PITCH dial again to begin the initialization process.

### Checking the Firmware version

1. With no disc loaded, simultaneously press and hold the SHIFT, DISPLAY buttons while pressing the PITCH dial. The currently installed firmware version will be displayed.