

Updating the Drive's firmware

These are the instructions to create an Update CD. This CD will be used to update the DV-RA1000 DVD drive's firmware using the unit's built-in DVD drive.

Creating the Drive Update CD

- (1) Have a blank CD-R data disc available.
- (2) Download the latest version of the firmware from the TASCAM website and burn the firmware file onto the blank CD-R disc. (Use the "Disc at once" method which complies with ISO9660: MS-DOS compatible)

NOTES: Be sure that the wall voltage matches the required voltage of the DV-RA1000 you are going to update.

Be careful that the power to the unit is not interrupted during the updating process.

*If the power is interrupted during the update process, the DVD drive could be damaged and have to be replaced.

Updating the firmware

- (1) While simultaneously holding down the FADE, SYNC REC and REWIND buttons, power on the unit. Continue to depress the buttons until the display reads "Drive update mode". The buttons can now be released.
- (2) When the drive's tray automatically opens, insert the Drive Update CD.
- (3) Press the ENTER button.
- (4) Once the Drive Update CD has been loaded, a confirmation message will appear in the display. Press ENTER.

NOTE: Our confirmation message example indicates that **T.0(X)** is going to be updated to **T.0(Y)**.

- (5) The update process is now started. A message will appear indicating that the process is running and that the contents of the drive's Flash ROM are being updated. Do not allow this process to be interrupted in any way.
- (6) When the update process has been completed, the tray will open and a confirmation message will be displayed. Remove the Drive Update CD and press the POWER button to turn the unit off.

*The update should take about 1 minute.

- (7) Press the POWER button again (to turn the unit on). The disc tray will close and the startup screen will be displayed followed by the unit's normal HOME screen. The unit can now be used normally.