TASCAM US-16x08 Release Notes

Most recent information

The most recent versions of the software/firmware for this unit are as follows.

Windows

Driver:	1.03 (Previously 1.01. Updated at this time)
Firmware:	1.00 (No new update)

Mac OS X

Settings Panel:	1.00 (No new update)
Firmware:	1.00 (No new update)

We request that you always use the latest versions of the unit software/firmware. For information about the latest firmware/software, check the TEAC Global Site (http://teac-global.com/).

New functions

Maintenance items

Windows Driver

■ **Version 1.03**

- Windows 10 is now supported.

  The driver V1.03 can also be used with Windows 7 and Windows 8.

Windows Driver

■ **Version 1.01**

- We had an issue with playback for users of software such as Google Chrome, Apple iTunes and foobar2000, which we have now rectified.

Checking the software/firmware versions

Before beginning to update the software/firmware, check the software/firmware version of the US-16x08 unit being used.

For details about how to check the software/firmware version, see "Opening the Settings Panel" in "6 – Using the Settings Panel" of the Reference Manual.

Windows Settings Panel screen

Procedures for updating the computer software

Preparing

- If the latest software has already been installed, there is no need to update it. Use it as is.
- Disconnect all cables connected to the unit.
- Set the phantom power switch to off.

Updating the Windows driver

1. Download the latest driver for the operating system you are using from the TEAC Global Site (http://teac-global.com/) and save it on the computer to be used with the unit.
2. Open the saved driver (zip file) on, for example, the computer desktop.
3. After uncompression, double-click the "TASCAM_US-16x08_X.XX.exe" ("X.XX" is the number of version) file in the folder that appears after uncompression to automatically launch the installation software.
4. After this, follow the installation procedures in "Installing the dedicated driver for Windows" in the Owner's Manual.