

This document includes important information that was not ready in time for manual printing. Where this document contradicts the manual, the information in this document should be used.

### **Changing the clock setting**

To change the clock setting of the FW-1082 from the surface:

1. The unit must be in **MON MIX** mode.
2. Press & hold **SHIFT** then press the desired clock setting key.

### **Japanese language display in SoftLCD**

Only DAWs and control surface protocols that support Unicode will transmit the data to SoftLCD that is required to display Japanese language. At this time only Sonar supports Unicode.

取扱説明書に以下の2点を補足いたします。

#### ● クロックの設定方法

FW-1082本体でクロックレート、クロックソースを設定するときは、SHIFTキーを押しながら希望のキーを押すように変更しました。(取扱説明書15ページ参照)

1. MON MIXキーを押してモニターミックスモードにします。
2. SHIFTキーを押しながら以下のいずれかのキーを押してクロックレートを選択します。

96kHz / 88.2kHz / 48kHz / 44.1kHz

3. SHIFTキーを押しながら以下のいずれかのキーを押してクロックソースを選択します。

INTERNAL / D IN

#### ● SoftLCDでの日本語表示

SoftLCDに日本語を表示できるのは、DAWとコントロール・プロトコルとがUnicodeをサポートしている場合のみです。2004年11月時点ではSONARのみがUnicodeをサポートしています。

---

## **TEAC CORPORATION**