

- 12cm以外のCD-R/CD-RW（8cmサイズ、名刺型など）には録音できません。
- A-B間リピートは、再生モードが通常モード（Continue）またはシングルモード（Single）のときに可能です。また、ディスクがCD-RまたはCD-RWの場合は、ファイナライズ済みでなければなりません。
- シャッフル再生モードのときは、総経過時間（TOTAL）と残り再生時間（TOTAL REMAIN）は表示されません。
- オートトラック機能がオンのときは、フェードイン／フェードアウト機能は働きません。
- ファイナライズ済みのCD-RWを消去またはディスクリフレッシュするには、まずいったんアンファイナライズしてください。
- 曲／ディスクのタイトルの表示について、取扱説明書30ページに「タイトルが12文字より多い場合はスクロールして表示します。」と書いてありますが、12文字以内でもスクロール表示になりますので訂正いたします。
- Rec Error、Erase Error、Tray Error、Disc Errorが発生したときは、自動的にトレイが開き、OPEN/CLOSEキーとSTOPキー以外のキーは受けつけません。この場合は、ディスクに異常がないかを確認の上、電源を入れ直し、再度操作してみてください。
- The CD-RW750 cannot record onto High Speed or Ultra Speed CD-RW discs. Only use 1x-4x CD-RW discs.
- Only use 12 cm CD-R/CD-RW discs for recording, as the CD-RW750 cannot record onto other types of media, such as 8 cm discs or card-type discs.
- The A-B repeat is possible only in the Continue or Single playback mode. It is not possible with an unfinalized CD-R or CD-RW disc.
- In the Shuffle playback mode, the total elapsed time and total remaining time are not displayed.
- The fade-in/-out recording cannot be performed when the auto track function is activated.
- To erase or refresh a finalized CD-RW disc, first unfinalize the disc and then erase or refresh.
- The disc/track title is scrolled across the display regardless of its length though in the Owner's Manual or Quick Start Guide it is written that the title is scrolled if it is longer than 12 characters.
- When the Rec Error, Erase Error, Tray Error, or Disc Error occurred, the tray automatically opens and the keys except the OPEN/CLOSE key and the STOP key are disabled. In this case, check to see that the disc is clean, turn the power off and on, and then try the operation again.

TEAC CORPORATIONPhone: +81-422-52-5082
D00811200A3-7-3, Nakacho, Musashino-shi, Tokyo 180-8550, Japan
Printed in China

- 12cm以外のCD-R/CD-RW（8cmサイズ、名刺型など）には録音できません。
- A-B間リピートは、再生モードが通常モード（Continue）またはシングルモード（Single）のときに可能です。また、ディスクがCD-RまたはCD-RWの場合は、ファイナライズ済みでなければなりません。
- シャッフル再生モードのときは、総経過時間（TOTAL）と残り再生時間（TOTAL REMAIN）は表示されません。
- オートトラック機能がオンのときは、フェードイン／フェードアウト機能は働きません。
- ファイナライズ済みのCD-RWを消去またはディスクリフレッシュするには、まずいったんアンファイナライズしてください。
- 曲／ディスクのタイトルの表示について、取扱説明書30ページに「タイトルが12文字より多い場合はスクロールして表示します。」と書いてありますが、12文字以内でもスクロール表示になりますので訂正いたします。
- Rec Error、Erase Error、Tray Error、Disc Errorが発生したときは、自動的にトレイが開き、OPEN/CLOSEキーとSTOPキー以外のキーは受けつけません。この場合は、ディスクに異常がないかを確認の上、電源を入れ直し、再度操作してみてください。
- The CD-RW750 cannot record onto High Speed or Ultra Speed CD-RW discs. Only use 1x-4x CD-RW discs.
- Only use 12 cm CD-R/CD-RW discs for recording, as the CD-RW750 cannot record onto other types of media, such as 8 cm discs or card-type discs.
- The A-B repeat is possible only in the Continue or Single playback mode. It is not possible with an unfinalized CD-R or CD-RW disc.
- In the Shuffle playback mode, the total elapsed time and total remaining time are not displayed.
- The fade-in/-out recording cannot be performed when the auto track function is activated.
- To erase or refresh a finalized CD-RW disc, first unfinalize the disc and then erase or refresh.
- The disc/track title is scrolled across the display regardless of its length though in the Owner's Manual or Quick Start Guide it is written that the title is scrolled if it is longer than 12 characters.
- When the Rec Error, Erase Error, Tray Error, or Disc Error occurred, the tray automatically opens and the keys except the OPEN/CLOSE key and the STOP key are disabled. In this case, check to see that the disc is clean, turn the power off and on, and then try the operation again.

TEAC CORPORATIONPhone: +81-422-52-5082
D00811200A3-7-3, Nakacho, Musashino-shi, Tokyo 180-8550, Japan
Printed in China