

# TASCAM TASCAM USB Audio Interface Driver

## TASCAM USB Audio Interface Driver installation guide (for Mac)

Follow the procedures below to install the driver for the first time on macOS High Sierra.

### Compatible products

US-122MK2, US-144MK2, US-322, US-366,  
US-1200, US-1800, UH-7000

### System requirements

Mac with Intel processor

Supported operating systems depend on the device. For details, please see the TEAC Global Site (<http://teac-global.com/>).

### Installing the driver

These installation procedures for the TASCAM USB Audio Interface Driver use screens from the TEAC USB HS Audio Driver as examples.

1. Go to the download page of your product on the TEAC Global Site (<http://teac-global.com/>), and download the Mac Driver.
2. Unzip the downloaded file, then open "xxxxx.pkg" (xxxxx is the driver name) in the extracted folder.



### NOTE

A warning window that says "xxxx cannot be opened because it is from an unidentified developer." may appear. If it appears, hold the Control key and right click, then choose "Open" from the menu, and click "Open" to continue with the installation.




3. Follow the instructions to proceed with the installation. Your user name and password will be required to proceed with the installation.




### NOTE

The user name and password required in this step are those which you use when you start up or log in to the Mac.

4. Choose "Restart" when the installation completes.



In this step, the following message may appear. If it appears, click "OK" to restart.




If you are installing the driver on a system that uses macOS High Sierra, follow steps 5 to 7, otherwise, jump to step 8.

5. After restart, open "Security and Privacy" in System Preferences.



6. Click "Allow" in the "General" tab. If "Allow" is disabled and grayed out, click the Lock icon [ ] to allow the setting to be changed.



- ① If the blocked driver is TASCAM USB Audio Interface alone, it shows "Ploytec GmbH".
- ② You can then enter the password you used in step 3.

### ATTENTION

This setting change MUST be carried out within 30 minutes of the driver being installed.

