

Default MIDI Programming Set-up

Control	Bank	Action	#	Channel	Ports
FLIP	All	Note On/Off	0	1	1
PAN	All	Note On/Off	1	1	1
AUX1	All	Note On/Off	2	1	1
AUX2	All	Note On/Off	3	1	1
AUX3	All	Note On/Off	4	1	1
AUX4	All	Note On/Off	5	1	1
AUX5	All	Note On/Off	6	1	1
AUX6	All	Note On/Off	7	1	1
AUX7	All	Note On/Off	8	1	1
AUX8	All	Note On/Off	9	1	1
SAVE/F1	All	Note On/Off	16	1	1
REVERT/F2	All	Note On/Off	17	1	1
ALL SAFE/F3	All	Note On/Off	18	1	1
CLR SOLO/F4	All	Note On/Off	19	1	1
MARKER/F5	All	Note On/Off	20	1	1
LOOP/F6	All	Note On/Off	21	1	1
CUT	All	Note On/Off	22	1	1
DEL	All	Note On/Off	23	1	1
COPY	All	Note On/Off	24	1	1
PASTE	All	Note On/Off	25	1	1
ALT/CMD	All	Note On/Off	26	1	1
UNDO	All	Note On/Off	27	1	1
HIGH	All	Note On/Off	28	1	1
HI-MID	All	Note On/Off	29	1	1
LOW	All	Note On/Off	30	1	1
LOW-MID	All	Note On/Off	31	1	1
F7	All	Note On/Off	32	1	1
F8	All	Note On/Off	33	1	1
F9	All	Note On/Off	34	1	1
F10	All	Note On/Off	35	1	1
READ	All	Note On/Off	36	1	1
WRT	All	Note On/Off	37	1	1
TCH	All	Note On/Off	38	1	1
LATCH	All	Note On/Off	39	1	1

Default MIDI Control Values

Control	Bank	Action	#	Channel	Ports
<NUDGE	All	Note On/Off	0	1	None
NUDGE>	All	Note On/Off	0	1	None
UP ARROW	All	Note On/Off	0	1	None
LEFT ARROW	All	Note On/Off	0	1	None
RIGHT ARROW	All	Note On/Off	0	1	None
DOWN ARROW	All	Note On/Off	0	1	None
SHTL	All	Note On/Off	0	1	None
<LOCATE	All	Note On/Off	0	1	None
LOCATE>	All	Note On/Off	0	1	None
SET	All	Note On/Off	0	1	None
IN	All	Note On/Off	0	1	None
OUT	All	Note On/Off	0	1	None
REW	All	Note On/Off	0	1	None
F FWD	All	Note On/Off	0	1	None
STOP	All	Note On/Off	0	1	None
PLAY	All	Note On/Off	0	1	None
RECORD	All	Note On/Off	0	1	None
FOOTSWITCH	All	Note On/Off	0	1	None
MUTE1	1	Note On/Off	48	1	1
MUTE2	1	Note On/Off	49	1	1
MUTE3	1	Note On/Off	50	1	1
MUTE4	1	Note On/Off	51	1	1
MUTE5	1	Note On/Off	52	1	1
MUTE6	1	Note On/Off	53	1	1
MUTE7	1	Note On/Off	54	1	1
MUTE8	1	Note On/Off	55	1	1
SOLO1	1	Note On/Off	56	1	1
SOLO2	1	Note On/Off	57	1	1
SOLO3	1	Note On/Off	58	1	1
SOLO4	1	Note On/Off	59	1	1
SOLO5	1	Note On/Off	60	1	1
SOLO6	1	Note On/Off	61	1	1
SOLO7	1	Note On/Off	62	1	1
SOLO8	1	Note On/Off	63	1	1

Default MIDI Control Values

Control	Bank	Action	#	Channel	Ports
SEL1	1	Note On/Off	64	1	1
SEL2	1	Note On/Off	65	1	1
SEL3	1	Note On/Off	66	1	1
SEL4	1	Note On/Off	67	1	1
SEL5	1	Note On/Off	68	1	1
SEL6	1	Note On/Off	69	1	1
SEL7	1	Note On/Off	60	1	1
SEL8	1	Note On/Off	61	1	1
MUTE1	2	Note On/Off	48	1	2
MUTE2	2	Note On/Off	49	1	2
MUTE3	2	Note On/Off	50	1	2
MUTE4	2	Note On/Off	51	1	2
MUTE5	2	Note On/Off	52	1	2
MUTE6	2	Note On/Off	53	1	2
MUTE7	2	Note On/Off	54	1	2
MUTE8	2	Note On/Off	55	1	2
SOLO1	2	Note On/Off	56	1	2
SOLO2	2	Note On/Off	57	1	2
SOLO3	2	Note On/Off	58	1	2
SOLO4	2	Note On/Off	59	1	2
SOLO5	2	Note On/Off	60	1	2
SOLO6	2	Note On/Off	61	1	2
SOLO7	2	Note On/Off	62	1	2
SOLO8	2	Note On/Off	63	1	2
SEL1	2	Note On/Off	64	1	2
SEL2	2	Note On/Off	65	1	2
SEL3	2	Note On/Off	66	1	2
SEL4	2	Note On/Off	67	1	2
SEL5	2	Note On/Off	68	1	2
SEL6	2	Note On/Off	69	1	2
SEL7	2	Note On/Off	60	1	2
SEL8	2	Note On/Off	61	1	2
MUTE1	3	Note On/Off	48	1	3
MUTE2	3	Note On/Off	49	1	3
MUTE3	3	Note On/Off	50	1	3
MUTE4	3	Note On/Off	51	1	3
MUTE5	3	Note On/Off	52	1	3
MUTE6	3	Note On/Off	53	1	3
MUTE7	3	Note On/Off	54	1	3
MUTE8	3	Note On/Off	55	1	3

Default MIDI Control Values

Control	Bank	Action	#	Channel	Ports
SOLO1	3	Note On/Off	56	1	3
SOLO2	3	Note On/Off	57	1	3
SOLO3	3	Note On/Off	58	1	3
SOLO4	3	Note On/Off	59	1	3
SOLO5	3	Note On/Off	60	1	3
SOLO6	3	Note On/Off	61	1	3
SOLO7	3	Note On/Off	62	1	3
SOLO8	3	Note On/Off	63	1	3
SEL1	3	Note On/Off	64	1	3
SEL2	3	Note On/Off	65	1	3
SEL3	3	Note On/Off	66	1	3
SEL4	3	Note On/Off	67	1	3
SEL5	3	Note On/Off	68	1	3
SEL6	3	Note On/Off	69	1	3
SEL7	3	Note On/Off	60	1	3
SEL8	3	Note On/Off	61	1	3
MUTE1	4	Note On/Off	48	1	4
MUTE2	4	Note On/Off	49	1	4
MUTE3	4	Note On/Off	50	1	4
MUTE4	4	Note On/Off	51	1	4
MUTE5	4	Note On/Off	52	1	4
MUTE6	4	Note On/Off	53	1	4
MUTE7	4	Note On/Off	54	1	4
MUTE8	4	Note On/Off	55	1	4
SOLO1	4	Note On/Off	56	1	4
SOLO2	4	Note On/Off	57	1	4
SOLO3	4	Note On/Off	58	1	4
SOLO4	4	Note On/Off	59	1	4
SOLO5	4	Note On/Off	60	1	4
SOLO6	4	Note On/Off	61	1	4
SOLO7	4	Note On/Off	62	1	4
SOLO8	4	Note On/Off	63	1	4
SEL1	4	Note On/Off	64	1	4
SEL2	4	Note On/Off	65	1	4
SEL3	4	Note On/Off	66	1	4
SEL4	4	Note On/Off	67	1	4
SEL5	4	Note On/Off	68	1	4
SEL6	4	Note On/Off	69	1	4
SEL7	4	Note On/Off	60	1	4
SEL8	4	Note On/Off	61	1	4

Default MIDI Control Values

Control	Bank	Action	#	Channel	Ports
GAIN ENCODER	All	Controller	48	1	1
FREQ ENCODER	All	Controller	49	1	1
Q ENCODER	All	Controller	50	1	1
DATA WHEEL	All	Controller	0	1	None
ENCODER 1	1	Controller	40	1	1
ENCODER 2	1	Controller	41	1	1
ENCODER 3	1	Controller	42	1	1
ENCODER 4	1	Controller	43	1	1
ENCODER 5	1	Controller	44	1	1
ENCODER 6	1	Controller	45	1	1
ENCODER 7	1	Controller	46	1	1
ENCODER 8	1	Controller	47	1	1
ENCODER 1	2	Controller	40	1	2
ENCODER 2	2	Controller	41	1	2
ENCODER 3	2	Controller	42	1	2
ENCODER 4	2	Controller	43	1	2
ENCODER 5	2	Controller	44	1	2
ENCODER 6	2	Controller	45	1	2
ENCODER 7	2	Controller	46	1	2
ENCODER 8	2	Controller	47	1	2
ENCODER 1	3	Controller	40	1	3
ENCODER 2	3	Controller	41	1	3
ENCODER 3	3	Controller	42	1	3
ENCODER 4	3	Controller	43	1	3
ENCODER 5	3	Controller	44	1	3
ENCODER 6	3	Controller	45	1	3
ENCODER 7	3	Controller	46	1	3
ENCODER 8	3	Controller	47	1	3
ENCODER 1	4	Controller	40	1	4
ENCODER 2	4	Controller	41	1	4
ENCODER 3	4	Controller	42	1	4
ENCODER 4	4	Controller	43	1	4
ENCODER 5	4	Controller	44	1	4
ENCODER 6	4	Controller	45	1	4
ENCODER 7	4	Controller	46	1	4
ENCODER 8	4	Controller	47	1	4

Default MIDI Control Values

Control	Bank	Action	#	Channel	Ports
MASTER FADER	All	Controller	7	1	None
FADER 1	1	Controller	32	1	1
FADER 2	1	Controller	33	1	1
FADER 3	1	Controller	34	1	1
FADER 4	1	Controller	35	1	1
FADER 5	1	Controller	36	1	1
FADER 6	1	Controller	37	1	1
FADER 7	1	Controller	38	1	1
FADER 8	1	Controller	39	1	1
FADER 1	2	Controller	32	1	2
FADER 2	2	Controller	33	1	2
FADER 3	2	Controller	34	1	2
FADER 4	2	Controller	35	1	2
FADER 5	2	Controller	36	1	2
FADER 6	2	Controller	37	1	2
FADER 7	2	Controller	38	1	2
FADER 8	2	Controller	39	1	2
FADER 1	3	Controller	32	1	3
FADER 2	3	Controller	33	1	3
FADER 3	3	Controller	34	1	3
FADER 4	3	Controller	35	1	3
FADER 5	3	Controller	36	1	3
FADER 6	3	Controller	37	1	3
FADER 7	3	Controller	38	1	3
FADER 8	3	Controller	39	1	3
FADER 1	4	Controller	32	1	4
FADER 2	4	Controller	33	1	4
FADER 3	4	Controller	34	1	4
FADER 4	4	Controller	35	1	4
FADER 5	4	Controller	36	1	4
FADER 6	4	Controller	37	1	4
FADER 7	4	Controller	38	1	4
FADER 8	4	Controller	39	1	4