

TASCAM

US-1641 Firmware Release Notes

Version 1.01 – October 30, 2007

Updates

Always ensure that you are running the latest driver software and US-1641 firmware by visiting <http://www.tascam.com>

Installation Frequently Asked Questions

Which should I update first, the firmware or the driver?

It is best to update to the latest driver first, then update the firmware.

How do I update my unit's firmware?

Simply download the latest firmware updater application from TASCAM's web site, launch it, plug your US-1641 into your computer, wait for the unit to be detected by the updater application, and then press the "write firmware" button.

Maintenance Items

Fixed in 1.01

- Firmware version 1.00 could drop MIDI output data in some rare situations. This has been corrected.
- The firmware now properly reports its USB power requirements to the computer.